

Variable ISI
Channel

CLE1200

Remote Command Manual

for

CLE1200-M2K, CLE1200-M2V

for firmware version 1.2

Rev 1.2

March 2019



1. Setup	2
1-1 Remote Interface	2
1-2 Ethernet	3
1-3 USB	4
2. Sample Code.....	8
2-1 Python Sample Code for Ethernet I/F.....	8
2-2 Python Sample Code for USB I/F	10
3. Commands.....	12
3-1 Conformity	12
3-2 Dedicated Commands.....	12
3-3 IEEE Std488-2 Command	18
3-4 SCPI Command.....	21
3-5 Tips: Initial Status.....	22
4 Error Code	23
Customer Support	25

1. Setup

This manual explains how to build a code to control CLE1200 series remotely.



1-1 Remote Interface

CLE1200 has two types of remote interface

- Ethernet
- USB 2.0

IMPORTANT:

When both Ethernet and USB are connected to CLE1200, the ethernet I/F will be disabled and only USB becomes available.

1-2 Ethernet

System requirement & Interfaces

- 10Base-T, 100Base-TX
- TCP/IP Socket protocol


Default IP address

Default IP address: 192.168.0.88

Subnet Mask: 255.255.255.0

Changing IP address

- Start a “internet browser”
- Type in the current IP address in the address bar
- A diagram starts up and click “Change IP Address” at the bottom-right section.



- Enter desired IP address and click “Apply”
- Restart CLE1200 by turning off and on


1-3 USB

System Requirement


- Windows XP, 7, 8, 10
- USB2.0 Interface (USBCDC Class)
- Artek USB driver (downloadable from our official website)

Installing the Driver

- When connecting CLE1200 with PC first time, Windows request drives. Insert the install CD into your PC and specify the directory in the CD drive.
 - Or Unzip (extract) the software package if you got an zipped file.
 - Run "Setup" from the CD drive or the unzipped folder.
- ❖ The CLE1200 is installed as one of the COM ports. Control is done by sending (or reading) IEEE compatible ANSI text to (and from) the COM port.
- ❖ When the driver is installed correctly, you will find it at Device Manager, under Ports(COM & LPT) as "Variable ISI Channel".



- ❖ If the driver does not install correctly, do the followings.
- Start "Device Manger" from Control Panel of MS-Windows
 - Look for "unknown device" or "CLE1200"
 - Select and double click the device, then you will see the following diagram.




- Update the driver specifying the CD drive or the unzipped folder.


Designating COM Port Number

The COM Port number for CLE1200 is automatically assigned by the system. You can always designate your desired number at property setting of the driver.

- Start Device Manager and double click the "Variable ISI Channel" under Ports(COM & LTP)



- Go to "Port Setting" Tab and click "Advanced".



- Change the COM Port Number.

Control from Other Operating System

The operation under the operating system rather than MS-Windows XP, 7, 8 and 10 is not guaranteed, however the following information is disclosed for user convenience.

CLE1200 communicates with a remote host via USB interface. USB CDC Class is applied and handled as RS232C serial interface. CLE1000 constructs USB I/F without FTDI part, but it complies the standard USB Communications Device Class. The Communications Device Class is not OS dependent and other operation system such as Linux has drivers comply to it.

2. Sample Code

Listed here are Python sample code both Ethernet and USB

2-1 Python Sample Code for Ethernet I/F

```
# Sapmle program for CLE1200
#!/usr/bin/python

import socket

def SocketOpen():
    print "OPEN"
    host = "192.168.0.88"
    port = 10001
    s = socket.socket()
    s.connect((host, port))
    s.settimeout(40)    #time out 40sec
    return s

def SocketSend(sckt,cmd):
    print "SEND[ "+ cmd + " ]"
    cmd+="\n"
    sendlen=sckt.send(cmd)
    return sendlen

def RecvLine(sckt):
    readstr=""
    while True:
        readchar=sckt.recv(1)
        if (readchar=="\n"):
            break
        else:
            readstr+=readchar
    print "RCV[ "+readstr+" ]"
    return readstr

def SocketClose(sckt):
    print "CLOSE"
```

```
sckt.close()
return

s=SocketOpen()
SocketSend(s,"*IDN?")
recvstr=RecvLine(s)
if (recvstr.find("CLE1200")==-1):
    print "Not CLE1200"
else:
    # read all error message
    while True:
        SocketSend(s,":SYST:ERR?")
        recvstr=RecvLine(s)
        if (recvstr.find("NO ERROR")>=0):
            break
        else:
            print recvstr

# to remote mode
SocketSend(s,":SYST:REM;*OPC?")
recvstr=RecvLine(s)

# IL mode
SocketSend(s,":ISI:MODE I;*OPC?")
recvstr=RecvLine(s)

# Question range & set frequency 28.4GHz
SocketSend(s,":ISI:RANG? 2840")
recvstr=RecvLine(s)
rang=recvstr.split(",")
print "Min:"+rang[0]
print "Max:"+rang[1]

# set 6.2dB (rang[0] <= 6.2 <= rang[1])
SocketSend(s,":ISI:IL 62;*OPC?")
recvstr=RecvLine(s)

# to local mode
SocketSend(s,":SYST:LOC;*OPC?")
recvstr=RecvLine(s)

SocketClose(s)
```

2-2 Python Sample Code for USB I/F

```
# Sample program for CLE1200

import serial
import time

ser = serial.Serial()
ser.port = 'COM20'
ser.timeout = 10

ser.open()
print "ser.open is ",ser.isOpen()

ser.write("*IDN?\n")
model=ser.readline()
print "*IDN? >> ",model

if (model.find("CLE1200")==-1):
    print "Not CLE1200"

# read all error message
while True:
    ser.write("SYSTem:ERRor?\n")
    errresult=ser.readline()
    print "SYSTem:ERRor? >> ",errresult
    if (errresult[0]=="0"):
        break

# set the remote control
ser.write(":SYST:REM;*OPC?\n")
print ":SYST:REM; >> ",ser.readline()

# to IL mode
ser.write(":ISI:MODE I;*OPC?\n")
print ":ISI:MODE I >> ",ser.readline()

# Question range & set frequency 28.4GHz
ser.write(":ISI:RANG? 2840\n")
print ":ISI:RANG? 2840"
recvstr=ser.readline()
rang=recvstr.split(",")
print "Min:"+rang[0]
print "Max:"+rang[1]
```

```
# set 6.2dB (rang[0] <= 6.2 <= rang[1])
ISI=ser.write(":ISI:IL 62;*OPC?\n")
print ":ISI:IL 62 >> ",ser.readline()

# set the local control
ser.write(":SYST:LOC;*OPC?\n")
print ":SYST:LOC; >> ",ser.readline()

ser.close()
```

3. Commands

3-1 Conformity

With some unique command dedicated for CLE1000, most of the commands are conformity with IEEEStd488-2 and SCPI-1990.

LF(0x0A) is always (and only) required at the end of the command.

3-2 Dedicated Commands

ISI:MODE

Change and Query Operation Mode (dB mode and % mode)

Syntax

ISI:MODE<String>

ISI:MODE?

Example

ISI:MODE P

Arguments

I	Sets the mode to dB mode
P	Sets the mode to % mode

Response

I	current mode - dB mode
P	current mode - % demo

ISI:IL

In dB mode, this command sets the target insertion loss in dB (0.0 – 99.9dB) and Frequency in GHz (0.10 – 40.00GHz).

The maximum and minimum values are limited by designated frequency. Query them by ISI:RANG?. ISI:RANG? Is mandatory before ISI:IL when changing the frequency.

Syntax

ISI:IL<NR1>,<NR1>

ISI:IL<NR1>

ISI:IL?

Example

ISI:IL 500, 4000

ISI:IL 500

Arguments

<NR1> 0 – 999 (0.1dB step)

<NR1> 10 – 4000 (0.01GHz step)

Response

<NR1>,<NR1>

Insertion Loss Value, Frequency

0.0 – 999 (0.1dB), 10 – 4000 (0.01GHz)

ISI:RANGe?

Queries available max and min insertion loss value at the designated frequency.

Syntax

ISI:RANGe?<NR1>

Example

ISI:RANG? 2000

Arguments

<NR1> 10 ~ 4000

Target Frequency , 0.01GHz step

Response

<NR1>,<NR1>

Minimum value, Maximum value

0 – 999 (0.1dB step)

ISI:LEVEL

In % mode, this command sets or queries insertion value by % in its dynamic range

Syntax

ISI:LEVE<NR2>

ISI:LEVE?

Example

ISI:LEVE 50.0

Arguments

<NR2> 0.0 – 100.0

Unit %

Response

<NR2> 0.0 – 100.0

OUTPut:ISI[:LEVEL]

This command is only for compatibility purpose with CLE1000 series.

SYSTem:BEEPer:STATe

Turns on/off the touch tone of LCD panel.

Syntax

SYST:BEEPer:STATe<string>

SYST:BEEP:STAT?

Example

SYST:BEEP:STATE ON

Arguments

OFF no tone, factory default

ON touch tone on

Response

OFF

ON

Remarks

This setting is not initialized by turning off/on nor RST. This is done only by this command.

SYSTem:COMMunicate:SOCKet:ADDRess

Sets and queries IP address

Syntax

SYSTem:COMMunicate:SOCKet:ADDRess<string>

SYST:COMM:SOCK:ADDR?

Example

SYST:COMM:SOCK:ADDR 192.168.0.88

Arguments

<string>	***.***.***.***	IP address
----------	-----------------	------------

Response

<string>	***.***.***.***	IP address
----------	-----------------	------------

Remarks

This setting is not initialized by turning off/on nor RST. This is done only by this command

:SYSTem:DELIimiter

Queries command delimiter

Default: LF(0Ah)

Syntax

:SYST:DELI<NR1>

:SYST:DELI?

Example

:SYST:DELI 0

Arguments

0	LF(0Ah)	factory default
1	CR(0Dh)	

Response

0 or 1

Remarks

This setting is not initialized by turning off/on nor RST. This is done only by this command.

:SYSTem:SRQ

Sets and queries SRQ function. Only effective for USB connection.

Syntax

:SYST:SRQ<NR1>

:SYST:SRQ?

Example

:SYST:SRQ 1

Arguments

0	SRQ off	factory default
1	SRQ on	CD signal
2	SRQ on	DSR signal
3	SRQ on	RI signal

Response

0 - 3

Remarks

This setting is not initialized by turning off/on nor RST. This is done only by this command.

DISPlay:BRIGhtness

Sets and queries the brightness of LCD display

Syntax

DISPlay:BRIGhtness<NR1>

DISP:BRIG?

Example

DISP:BRIG 100

Arguments

0 – 100 Factory default: 80

Response

0 – 100

Remarks

This setting is not initialized by turning off/on nor RST. This is done only by this command.

DISPlay:AUTOoff

Sets and queries the time duration for automatic turning off of the LCD display

Syntax

DISPlay:AUTOoff<NR1>

DISP:AUTO?

Example

DISP:AUTO 5

Arguments

0 – 120 in minutes, 0 for no turning off

Response

0 – 120

Remarks

This setting is not initialized by turning off/on nor RST. This is done only by this command.

3-3 IEEE Std488-2 Command

***CLS**

Clear Status - Clears up entire status

Syntax

*CLS

***ESE**

Event Status Enable – Specifies (or queries) the register bit value of Event Status Enable.

Syntax

*ESE <NR1>

*ESE?

Arguments

<NR1> 0 ~ 255

Response

<NR1> 0 ~ 255

***ESR?**

Event Status Register – Queries and clears Standard Event Status Register (SESR).

Syntax

*ESR?

Response

<NR1> 0 ~ 255

***IDN?**

ID Query – Queries the device's ID code

Response

(example) ARTEK,CLE1200,000112179,1.00

***OPC**

Operation Complete – Returns “1” when all operations complete and sets OPC bit (bit0) at SESR register.

Syntax

*OPC

*OPC?

Response

1 for *OPC?

***PSC**

Specifies whether it clears the registers for ESER and SRER at system boot.

Syntax

*PSC <NR1>

*PSC?

Arguments

<NR1> 0 Do not clear the register

<NR1> 1 Clears the register

Response

0 or 1

***RST**

Reset – Halts all the process and initiate the device to the minimum value setting.

Syntax

*RST

***SRE**

Service Request Enable – Specifies (or queries) the register value of Service Request Enable (SRER)

Syntax

*SRE <NR1>

*SRE?

Response

<NR1> 0 ~ 255

***STB?**

Read Status Byte – Queries the Read Status Byte Register. Upon this command, the bit6 of STB becomes MSS.

Syntax

*STB?

Response

<NR1> 0 ~ 255

***TRG**

Triger – This product does not support this function.

***TST?**

Selftest – This product does not support this function.

Syntax

*TST?

Response

<NR1> 0

***WAI**

Wait – Halts the followed command until the current command completes.

Syntax

*WAI

3-4 SCPI Command

SYSTem:ERRor[:NEXT]?

Returns the oldest error information and clears the error.

Response

-200,"Execution error"

SYSTem:VERSion?

Returns SCPIversion

Response

"1990.0"

Remote / Local

SYSTem:LOCal

Sets this device LOCAL.

Syntax

SYST:LOC

SYSTem:REMote

Sets this device REMOTE mode. Disables the controls at local device except “Local switch”.

Syntax

SYST:REM

SYSTem:LLOut

Disables “Local switch” at local device.

Syntax

SYST:LLO

3-5 Tips: Initial Status

1) Difference between Start-up and *RST

When System Start-up

ISI Value: as the front panel dial specifies

When *RST executed

ISI Value becomes minimum

2) No Trigger supported

3) Multiple commands can be received up to 127 letters

Command Example

:SYS:REM

Sets Remote operation

:SYST:LLO

Disables the front panel operation

*RST;*OPC?

Initializes the output setting. Returns 1 once done.

ISI:RANG? 3000

Gets available minimum and maximum insertion loss value at 30.00GHz

ISI:IL 123;*OPC?

Sets insertion loss value 12.3dB at 30.00GHz (0.1dB step).

:SYST:LOC;*OPC?

Sets Local operation. Returns 1 once done.

4 Error Code

0	0, "No error"
-102	-102, "Syntax error"
-103	-103, "Invalid separator"
-108	-108, "Parameter not allowed"
-110	-110, "Command header error"
-113	-113, "Undefined header"
-200	-200, "Execution error"
-201	-201, "Invalid while in local"
-220	-220, "Parameter error"
-222	-222, "Data out of range"
-223	-223, "Receiving data overflow"
-230	-230, "Internal Data Error"
-240	-240, "Hardware error"
-310	-310, "System error"
-311	-311, "Memory error"

-315

-315, "Lost Configuration Memory"

-350

-350, "Queue overflow"

-365

-365, "Time Out error"

-500

-500, "Power ON"

-800

-800, "Operation complete"

Customer Support

Please contact with our customer support center.

Worldwide Sales & Support



Developed By

